



1. Verify fit, shade, and contour.
2. Etch internal of veneer with phosphoric acid.
3. Silanate veneer.
4. Etch tooth with phosphoric acid.
5. Place bonding agent on tooth I do not light cure.
6. Place unfilled resin on internal of veneer I used as wetting agent.
7. Place luting resin in veneer and seat completely.
8. Remove excess luting resin with brush or rubber tip.
9. Polymerize veneer with light curing unit I polish and finish.